

POURING CANDLES



CHECKLIST

- 1 empty 300 g Cavendish & Harvey Bonbon Jar
- 1 candle flat wick
- Paraffin wax
- Fragrance oil for candles
- A small and a large pot
- A spoon
- Gift ribbon

STEP 1

Melt the paraffin wax together with 2 - 3 tropic fragrance oils over a water bath.



STEP 2

Place the wick in the middle of the glass and fix it with a tablespoon of liquid candle wax.

STEP 3

To avoid holes in the candle, fill the glass approx. 4 - 5 times and let it cool down each time.



STEP 4

Place the ribbon around the top of the Cavendish & Harvey Jar and decorate it with a bow.

