

WILD BERRY POPCORN



INGREDIENTS FOR 1 PORTION

- 80g of popcorn corn
- 175g of wild berry drops
- 4 tbsp of sunflower oil

PREPARATION

- Heat the oil and corn together with the lid on medium-high heat. Toss until the corn is fully popped and set aside in a closed jar.
- Heat the Wild Berry Drops until the candies are melted but not caramelised.
- Pour the liquid candy mixture directly onto the popcorn in the container and shake vigorously to mix. Place the finished popcorn on a baking sheet to cool and then enjoy immediately.